


Using The ActiveSense® system AIR1 Sensor in Rodent Bait Stations

ITEMS NEEDED



AIR1 SENSOR



DOUBLE-SIDED TAPE
(PROVIDED)



ALCOHOL WIPES



PAINT BRUSH

STEPS

1.

REMOVE DEBRIS

Remove any debris in trap with paint brush.



2.

CLEAN

Use alcohol wipe to clean front wall (interior side) of runway where the AIR1 sensor will be attached, allowing time for surface to dry.



3.

TAPE

Attach double-sided tape to back of AIR1 sensor. Use either the tape provide with AIR1 sensor or other quality alternative.



4.

ATTACH SENSOR

Attach AIR1 sensor to interior front wall center of trap with label facing up. Ensure the sensor lens is facing into the bait chamber/interior.



BAIT STATION OPTIONS

Bell Protecta Bait Station
Bell Protecta Sidekick Bait Station
Bell Protecta Evo Express Bait Station
Liphatech Aegis-RP Bait Station